

## P2 DISPOSABLE FOLD-FLAT RESPIRATOR

The Alpha Solway H-2 is a horizontal fold flat disposable respirator designed to offer an excellent fit.

### KEY FEATURES

- › Lightweight, fold flat respirator
- › Flexible nose bridge
- › Electrostatic filter media
- › Conforms to EN 149:2001+A1:2009 FFP2 NR
- › Tapered shape for enhanced fit
- › Premium quality straps ensure stability on the face
- › Non ferrous nose bridge
- › Valve free
- › Latex and silicone free
- › Assigned Protection Factor (APF) 20
- › Meets splash resistant requirements of EN 14683:2019+AC:2019



LATEX FREE

### ORDERING INFORMATION

**Part Number:** H-2

**Packaging:** 20 singles per box  
12 boxes per case

**Certification:** EN 149:2001+A1:2009  
FFP2 NR

### SUITABLE APPLICATIONS

Protects from non-toxic dusts and oil/water based particulates. Some suitable applications include:

- |                                |                                     |
|--------------------------------|-------------------------------------|
| ▪ Construction                 | ▪ Mining                            |
| ▪ Healthcare and personal care | ▪ Ship Building/Repair              |
| ▪ Dentistry                    | ▪ Underground Civil Engineering     |
| ▪ Emergency Services           | ▪ Woodworking Industry              |
| ▪ Infection Control            | ▪ Disposal of Waste                 |
| ▪ Pharmaceutical Industry      | ▪ Manufacture of Batteries (Ni-Cad) |
| ▪ Metalworking                 |                                     |

## TECHNICAL SPECIFICATIONS

### MATERIALS

COMPONENT	MATERIAL
Outer Cover:	Polypropylene
Inner Cover:	Polypropylene
Filter Media:	High Filtration Efficiency (Non-woven textile)
Headstrap:	Textile Elastic
Nose Bridge	Aluminium

### DIMENSIONS

ITEM	LENGTH (mm)	WIDTH (mm)	HEIGHT (mm)
Respirator	224	96	N/A

## CERTIFICATION

Certified to the requirements of EN 149:2001+A1:2009 as FFP2 NR disposable respirator.

Type-Examination, (Module B), Certificate issued by: EU - CCQS Certification Services Limited, [N.B. No. 2834].

Module D Certification, under the surveillance of: Notified Body - SGS Fimko Oy, [NB.No. 0598].

## RECOMMENDATIONS FOR USE

This respirator is disposable and recommended for single shift use only.

Do not attempt to clean or re-use.