

# Pharmacy Plus Bluetooth Enabled Refrigerator

## 158L Pharmacy Plus Undercounter Fridge with Solid Door – Integrated Drawers

Product code PPSR158BT-DWP

SKU code 444411387



### Key features

- ✓ Temperature range of +2°C to +8°C
- ✓ Audible and visual temperature alarms
- ✓ Solid and glass door options
- ✓ Integrated lock, supplied with 2 keys for added security



### Bluetooth Connected Controller

Our controller is Bluetooth enabled and allows for simple, contactless monitoring of temperature and alarm history, via the official Lec Medical app. Battery back-up, provides continuous temperature monitoring in the event of power outage.

### Lec Medical Smartphone App

Contactless local monitoring of air and load temperatures via smart phone app. Downloadable temperature report and alarm history.

### Intelligent Fan Management

Smart fan optimisation aides in temperature stability following door openings, minimising fan activity when door is open to reduce the rate of temperature increase.

### Dual Probe Temperature Monitoring

Our dual probe system offers greater temperature accuracy within your appliance, simultaneously measuring both air and product temperatures.

### Integrated Drawers

These slide out drawers include dividers to assist with stock rotation and keep contents organised

|                                     |                                |
|-------------------------------------|--------------------------------|
| SKU Code                            | 444411387                      |
| Product Code                        | PPSR158BT-DWP                  |
| Gross Capacity (litres)             | 158L                           |
| Net Capacity (litres)               | 145L                           |
| Unit External Width (mm)            | 595mm                          |
| Unit External Depth (mm)            | 600mm                          |
| Unit External Height (mm)           | 850mm                          |
| Product Weight (kg)                 | 39.86kg                        |
| Packed Width (mm)                   | 640mm                          |
| Packed Depth (mm)                   | 660mm                          |
| Packed Height (mm)                  | 910mm                          |
| Packed Weight (kg)                  | 44.91kg                        |
| Country of Origin                   | UK                             |
| Internal Dimensions (mm) (WxDxH)    | 495mm x 480mm x 720mm          |
| Temperature Range                   | +2°C to +8°C                   |
| Colour                              | White/green                    |
| External Finish                     | Painted Steel                  |
| Internal Finish                     | HIPS*                          |
| Type of plastic                     | SRL800 (HIPS/ABS mix)          |
| Door Finish                         | Painted Steel / HIPS*          |
| Door Type                           | Solid                          |
| Door Style                          | Hinged, Reversible             |
| Door Liner                          | Flat                           |
| Number of Door Trays                | N/A                            |
| Number of Door Tray Positions       | N/A                            |
| Door Open Depth (mm)                | 1150mm                         |
| Replacement Door Seal               | Yes                            |
| Open Door Sensor                    | Yes                            |
| Lock                                | Yes, 2 Keys                    |
| Adjustable Feet (number & position) | 4 All adjustable               |
| Porthole                            | Yes                            |
| Porthole Size                       | 16mm                           |
| Porthole Location                   | Rear Bottom (Right)            |
| Temperature Display on Panel        | Yes                            |
| Temperature Alarm                   | Yes                            |
| Remote Alarm Contacts               | Yes                            |
| Audible Alarms                      | Yes                            |
| Visual Alarms                       | Yes                            |
| Number of Shelves/Drawers           | 4                              |
| Number of Shelf Positions           | 3 Fixed                        |
| Shelf Size (mm) (WxDxH)             | N/A                            |
| Shelf Size 2 (mm) (WxDxH)           | N/A                            |
| Shelf Material                      | N/A                            |
| Drawer Size (mm) (WxDxH)            | 419mm x 374mm x 60mm           |
| Drawer Size 2 (mm) (WxDxH)          | N/A                            |
| Drawer Material                     | ABS                            |
| Number of Baskets                   | 1                              |
| Basket Material                     | Polythene Coated Wire          |
| Basket Size (mm) (WxDxH)            | 485mm x 255mm x 171mm          |
| Interior Light                      | Yes                            |
| Light Type                          | LED                            |
| Light Activation                    | Door Switch / App              |
| Fan                                 | Yes - Tangential               |
| Spark Free                          | No                             |
| Defrost setting                     | Auto (Off Cycle)               |
| Controller Type                     | Digital BT, External           |
| Battery Back Up/Hours               | Yes/48hrs                      |
| Bluetooth                           | Yes                            |
| Number of Probes                    | 2                              |
| Probe Type                          | Air & Load (Silicone Oil)      |
| Ambient Temperature Range           | 10°C to 32°C                   |
| Refrigerant Type                    | R600a/28g                      |
| UK 3 Pin Plug                       | Yes                            |
| Other Plug Types Available          | No                             |
| Voltage Supply                      | 220-240V                       |
| Frequency (Hz)                      | 50Hz                           |
| Max Power (W)                       | 101W                           |
| Max Current Rating (A)              | 0.78A                          |
| Energy Consumption (kWh/24h)        | 0.69kWh/24h                    |
| Energy Consumption AE (kWh)         | 219kWh                         |
| Noise Level (dB)                    | 40.1dB                         |
| Insulation Thickness (mm)           | 45mm                           |
| Insulation Type                     | High Density Polyurethane Foam |
| Blowing Agent                       | Cyclopentane                   |
| Anti-Microbial Handle               | Yes                            |